
MUDROOM

ASSEMBLY INSTRUCTIONS





Congratulations on your purchase! For any questions reach out to support@modularclosets.com or call 844-969-4247

Thank you for choosing Modular Closets and our Mudroom system!

We are committed to providing you with a seamless and efficient storage solution that enhances the organization and functionality of your space. Before you embark on assembling your new Mudroom system, we want to emphasize a crucial step to ensure a smooth and successful installation.

Important: Understanding Your Components

Before you begin the assembly process, it is essential to familiarize yourself with the components provided in your package. Our Mudroom system includes various boxes containing different parts designated for specific towers. Properly identifying and organizing these components will prevent confusion and streamline the installation.

What You Need to Do


- 1. **Inventory Check:** Begin by unpacking all the boxes and verifying the contents against the parts list provided. Ensure that you have all the necessary components and hardware.
- 2. Label and Sort: Carefully read the labels on each box and sort the components according to the designated towers. This step is critical as it will help you avoid mixing parts that belong to different sections of the closet system.
- Check Sizes: Verify the sizes of the components against the measurements specified in your design PDF. Ensuring that each part matches the intended dimensions is crucial for a proper fit and installation.
- 4. Reference Your Design PDF: Use the design PDF provided with your order to map out the correct placement of each component. This document will guide you in matching the parts to their specific locations within the closet system.
- Read the Instructions: Thoroughly read through the entire instruction manual before starting the assembly. Understanding the overall process and the sequence of steps will save you time and effort.

By taking the time to carefully organize, understand your components, and reference your design PDF, you set the stage for a successful and stress-free installation. We are confident that with a little preparation, you will find the assembly process straightforward and rewarding. Thank you for your attention to these important details.


Now, let's get started on transforming your space with your new Mudroom closet system from Modular Closets!



The bench will be built first in the following steps. On page 20 starts the Upper Assembly. On page 34 starts the drawer boxes. On page 49 starts the doors.





Boxes Needed







Hardware Packs Needed HRDP-MDR








From Box MDR-BSP take the bench side panels and insert the hardware as shown.






For all center panels in boxes MDR-BCP insert the double camposts and longer wood dowels until about halfway. Insert the screw dowel. Flip over and insert second screw dowel





From the box MDR-BFS, insert camlocks in to the shelves and cleats, and rafixes into the toekicks.






Connect the cleats and shelves to the left side panel.








Carefully, flip the unit to the side and tighten the camlocks on the underside. (We recommend you line your floor to prevent scratches.)





Remove the pre-installed wooden dowels from cleat and shelf. Once removed, connect the center panel to the shelf and cleat.






After removing the pre-installed dowels on one side, connect a shelf and cleat to the center panel. Do not remove any dowels from the other side of the cleat and shelf unless connecting to another center panel.









Step 10Connect the right side panel and tighten the camlocks.







Very carefully, flip the unit back upright and then tighten the camlocks for the cleats in the back




Step 13Insert the hardware into the bench top




This step requires the 'shorter' wooden dowels previously set aside. Please ensure you are using the correct size variant for this step.




Campost













The upper shelves assembly will begin now



Boxes Needed


MDR-USP

Mudroom Upper side panel pack




MDR-UCP Mudroom Upper Center Panel Pack(1 or 2 Pack)

> Single pack or double pack or both depending on mudroom size



Mudroom Upper Shelf Pack-(19.5" / 25")

Single pack or double pack or both depending on mudroom size




Tools needed

Rubber mallet


Philips screw driver








Hardware Packs Needed HRDP-MDR




Insert hardware into Side Panels and Center Panels. Use the screw dowel in




Step 1 (continued)

For Center Panels (if applicable), flip the panel over and insert the hardware into the corresponding spots.






Insert rafix clips into a fixed shelf and wedgefixes into a cleat. (Supplied third shelf will be used later as an adjustable shelf.)




Insert OVVO dowels into the appropriate bottoms of all side and center panels

Please note that the second set of pre-drilled dowel holes at the bottom of the panel can be used when offsetting the unit from the wall to account for standard baseboards







Take one side panel and one side/center panel (if applicable) and insert them



Step 5 Slide the cleat into the 4 lower screw dowels installed on the panels. 2 Person Recommended





Step 7 Using a Ph






2 Person Recommended






Repeat steps 4-7 for the upper fixed shelf and cleat between the two side/center panels.




Connect next center/side panel on top of the bench (all center panels should be used before the remaining side panel).




2 Person Recommended




Step 10Repeat steps 5-9 for all remaining sections.




The drawer boxes will be built next.



Drawer assembly Boxes Needed




(There is a 1 per pack and 2 per pack box)



MDR-DRB Mudroom Drawer Boxes

(There is a 1 per pack and 2 per pack box)



Tools needed


Philips screw driver



Rubber mallet





Drawer Locks and Slides (separate box)






Hardware Packs Needed HRDP-MDRDW










Removing the parts from MDR-DRB(s), insert cam locks, cam posts and wooden dowels in the drawer sides and back as shown below.












Step 5 Insert cam locks and camposts into drawer front as shown below. Wooden Dowel Campost







Flip over the drawer and put the lock for slides in each corner and screw in as shown. Repeat steps 2 - 9 for all drawers.



Attach the drawer slides to the lower half on both sides in each open cubby of




Repeat for all remaining drawer slides on each open section.






Attaching drawer boxes to the rails is as simple as placing the drawer box into its correct place. Simply keep the rails retracted, take the drawer and slide it into the bench opening. It should connect automatically. If not see the step below.




Step 11b

If the slides did not catch, here is what to look for. On the drawer locks, the lever operated hinge should catch on the open slot of the extendable portion of the drawer slide shown below. The slide should also hook on to the back side of the drawer.






The door asembly on the top shelves will be built next.




Door Assembly Boxes Needed



MDR-DO

(19.5" has 1 per pack and 24" has 2 per pack)




Tools needed


Door Hinges/Plates (Hardware Pack)

Philips screw driver

Rubber mallet












Hardware Packs Needed ALT-HRDP-DO




Take the hinge plate in the provided door hardware and line up the plate screws to fit into the top section of your choice.






Step 3

Slide door hinges from provided door hardware into the open slots of the doors.







Using a screwdriver tighten only the highlighted captive screws on the door hinges 90 ° clockwise to lock them in place. Do not use a drill.




Step 4b (optional)


Install Door Knob by securing 1" screw into any of the pilot screws on the back of the door. You may have to use a drill bit to punch through hole.





Repeat steps 1-5 for all remaining doors. Please note larger variants of the mudroom will use double doors for each top cubby.





To install supplied rod cups please use this printed sheet as a guide.
Line up this paper's printed stencil holes, labeled A and B, to the
vertical bores on the upper assembly panels. Use the center pilot line
to accurately drill in the rod cups to the appropriate side/center panels





Measurement Guide (Please turn paper horizontally.)



